




## Instruction Manual



The Mhamo Deodorizer is designed for use in consumer-grade refrigerators for general deodorization and long-lasting freshness.

v1

### Product Overview



1. Sliding Mode Switch
2. Status Indicator Light
3. Charging Port
4. Magnetic Mount Attach Point
5. Mounting Sticker
6. Removable Charcoal Filter Grill
7. USB Charging Cable

### How To Use

#### Charging Mhamo

1. Please use the included USB Charging Cable for the best performance. Using other power sources could damage Mhamo.
2. During charging the Status Indicator Light will turn RED, once the device is fully charged the indicator light will turn WHITE.
3. Fully charge before use. Charging time is approximately 1.5 hours.

### Mounting Mhamo

1. Thoroughly clean and dry the surface area where you will place Mhamo.
2. Remove the backing film and apply the Magnetic Mounting Sticker to the fridge surface. Press and hold the sticker firmly for 30 seconds to ensure the best adhesion.
3. Select your preferred mode [MAX or ECO] via the Sliding Mode Switch on Mhamo.
  - a. In MAX mode, the Status Indicator Light will be BLUE and the battery will last approx. 3 days.
  - b. In ECO mode, the Status Indicator Light will be GREEN and the battery will last approx. 30 days.
4. Mount Mhamo to the Magnetic Mounting Sticker.

### Changing The Charcoal Filter

For the best performance, it is recommended to change Mhamo's charcoal filter every 30-60 days.

1. Turn Mhamo off.
2. Gently lift up the release latch of the Removable Charcoal Filter Grill.
3. Remove the grill.
4. Replace the charcoal filter.
5. Insert the top catches on the grill into the slots and gently refit the grill back into Mhamo.

### Tips for Care & Cleaning

1. Please disconnect the charging cable and switch Mhamo OFF before cleaning.
  2. Remove all foreign objects and debris on Mhamo's surface.
  3. Clean Mhamo with a soft, non-abrasive cloth.
- ⚠ IMPORTANT**
- Never clean with harsh chemicals, acid, gasoline, alcohol, etc.
  - Never clean with compressed air.
  - Never clean with abrasive materials.
  - Do not insert any sharp objects inside the vent or the device can become damaged.
  - There are no user-serviceable parts inside, do not attempt to disassemble Mhamo.

### Product Features

- Lightweight and compact design
- Single slider switch operation
- Magnetic mounting included
- Charcoal mesh filter neutralizes odors
- Long-lasting rechargeable battery

### Product Specifications

- Charging Port: C-cable
- Battery: Rechargeable 1,000 mAh 3.7V
- Operational Temperature: 0 to 35°C (32 to 95°F)
- Operational Humidity: 30-85%
- Product Size: 67x67x33mm
- Product Weight: 73g

### Get in Touch

Have questions about Mhamo?

You can contact our helpful customer service team by going to [support.mhamostore.com](https://support.mhamostore.com) Or by scanning the QR code. We're always happy to help!

Activate your warranty at

[mhamostore.com/warranty-registration.html](https://mhamostore.com/warranty-registration.html)



### Download the app

Mhamo Fresh App keeps your fridge smelling fresh and reduces food waste. Simply log your food items and get notified before they expire.

Search for food storage tips and add your own tricks! Plus it can remind you to charge your deodorizer and change the filter.



For iOS®

iOS is a trademark of Cisco Technology, Inc.



For Android™

Android is a trademark of Google LLC.

### ⚠ Warnings and Precautions

- Keep it out of reach of infants and children.
- Do not place the device in the freezer section of the fridge or the device will be damaged. The safe working temperature is from 0 to 35°C.
- Do not expose the device to extreme heat or freezing temperatures. If you use the product for purposes other than those described, the product may be damaged. In addition, improper use can result in short circuits, fires, electric shocks, or other hazards.
- The device is not waterproof. Do not operate the device in wet environments or any setting that would subject the device to rain, water splash, extreme humidity, etc.
- Before maintenance and/or cleaning, please turn off the device and unplug the charging cable to prevent the risk of electric shock.
- At the end of the product's life, please dispose of the product in accordance with local recycling regulations for battery-equipped products.



FCC NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-3 (B)/NMB-3(B)