

KOREJETPULSE™

CORDLESS PORTABLE BLENDER

Instruction Manual




CAUTION:

Please follow the important safety warnings below. Failing to do so can result in injury and/or harm to you and others:


- Do not remove the jug cover when the blender is working.
- Blades are sharp. Contact with the blades' edges can result in laceration, be careful when cleaning.
- If the blender is blocked by food when blending, turn it off immediately and check to see if anything is causing a blockage. Clear out the blockage and then turn on the blender. Always turn off the blender before checking.
- Do not allow children to operate this blender. Store or keep out of reach from children.
- Do not fill over 2/3 of the jug. Make sure the lid cover is fully closed before operation.
- Do not use this blender for grinding hard dry ingredients like nuts, coffee, beans etc. This will damage the blender and reduce its operational life.
- To maintain freshness, consume the food/drink immediately after blending.
- Do not remove jug while blending, there is also an auto stop when removing the jug while blending.
- While charging, the blender will not work.



PACKAGE CONTENTS:



1 KOREJETPULSE™
Cordless Portable
Blender




2 Charging Cable

Specifications:


Volume:	400ml
Battery specification:	5,000mAh
Rated current:	17A
Rated voltage:	7.4V ---
Motor specification:	7.4V ---
Rated power:	126W
Motor rotating speed:	16,500rpm ± 15%

QUICK INSTALLATION:

1. Please check that both the lid cover and base have their silicone gaskets in place.
2. Put the jug onto the main base and then twist clockwise until fully locked. (Press the power button to start blending with the white light ring on)



CHARGING:



1. Insert the Micro USB side of the cable into the charging port of the blender.
2. Insert the USB-A side of the cable into an adapter or power bank etc (Not included).

NOTE:

The red light indicates the machine is charging. When charging is completed, the light will turn white. The blender will not work during charging.

WHITE LIGHT INDICATION:

1. **Blending Function:** Press the power button and hold for 2 seconds. The blender will start automatically, and the white light ring will be on. The blender will stop automatically after 45 seconds.
2. **Ice Crush Function:** Press the power button twice continuously for the ice crush blend speed. The blender will start automatically, and the white light ring will be on. The blender will stop automatically after 45 seconds.
3. **Full Charge:** When fully charged, the white light will be on while plugged in.

RED LIGHT INDICATIONS:

1. When the jug is separated from the base or not installed correctly, the blender will not work, and the red light will flash 5 times. (This indicates that it will not work)
2. When charging, the red light will stay on. The blender will not work while charging.
3. If any food is overloading the jug or something is blocking the blender from working during operation, it will stop automatically, and the red and white lights will flash alternately.
4. The red light will flash 10 times when the battery has no power. Please charge the blender before operating.
5. When the ingredients and/or liquids sit below the height of the blades, the blender will stop after 5 seconds for protection and the red light will flash 3 times.

BLENDING JUICE OPERATIONS:

1. Cut food into several pieces, remove skin and seeds. (around 1.5-2.0cm)
2. Pour water or milk into the jug.
3. Angle the blender to 45° downward, then turn on the machine.
4. To help the food blend, shake 5-8 times during the blend for around 30-40 seconds.

CRUSHING ICE OPERATIONS:

1. Prepare 40-45g of ice cubes. (around 1.5 x 2.5cm)
2. Put the ice cubes into the jug.
3. Angle the blender to 45° downward, and then start the blender by pressing the switch twice continuously.
4. Flip the blender upright and shake the jug gently for better blending.

WARNING:

Please follow the important safety warnings below. Failing to do so can result in injury and/or harm to you and others:

- If your jug is damaged please stop the blender immediately. To avoid further damage, check for any leakage or unscrew the jug to check for loose screws or other parts that may be malfunctioning.
- It is best to charge the blender for about 3-5 hours.
- The best blending performance is 100g of food + 200g of liquid (±10%).
- The blender should only be used when water, milk or other liquids are inside the container at a height above and covering the blades. If the food does not blend, add more liquid. Do not fill above 2/3 of the jug.
- Do not wash the base of the blender with water.
- Do not submerge the base in water. If water gets into the switches or charging port, the blender will be damaged.